CONTROL PANEL PARTS

For Models: MH6130XEB1, MH6130XEQ1
(BLACK) (DESIGNER WHITE)

MICROWAVE
HOOD
COMBINATION



Literature Parts

1		Literature Parts
	LIT4359626	Guide, U & C
	LIT4359455	Instructions, Installation
	LIT4359670	Tech Sheet
	LIT4359456	Guide, Cooking
2		Control Panel
	4359480	Black
	4359479	White
	4358762	Screw
3	4359481	Brack
4		Key Membrane
	4359684	Black
	4359685	White
5	4359661	PCB Sub Assy.
	4358883	Screw

DOOR PARTS

For Models: MH6130XEB1, MH6130XEQ1
(BLACK) (DESIGNER WHITE)



1		Door Assembly
	4359978	Black
	4359976	White
2		Frame, Door
	4359979	Black
	4359977	White
3	4359467	Tape, Seal
4		Latch
	4359860	Black
	4358546	White
5	4358607	Spring, Latch
6		Panel, Door
	4359470	Black
	4359469	White
7		Glass, Door
	4359683	Black
	4359547	White
8		Handle, Door
	4359474	Black
	4359473	White
	4358479	Screw
9		Choke, Cover
	4359476	Black
	4359475	White

CABINET PARTS

For Models: MH6130XEB1, MH6130XEQ1

(BLACK) (DESIGNER WHITE)



1		Outer Case
	4359488	Black
	4359487	White
	4358381	Screw
2	4358928	Mounting Bracket
	4358192	Screw
3		Cavity Assy (Not Serviceable)
4		Grille Vent
	4359490	Black
	4359489	White
	4358762	Screw
5	4358759	Bracket Front
	4358192	Screw
6	4358816	Bracket, Grille
7	4359616	Cover, Power Cord
	4358192	Screw
	4359377	4358381 Screw
9		Plate, Mount

MAGNETRON AND AIR FLOW PARTS

For Models: MH6130XEB1, MH6130XEQ1

(BLACK) (DESIGNER WHITE)



1	4359687	Magnetron
	4358489	Screw
2	4359494	H.V. Transformer
	4158747	Screw
3	4359497	Bracket, H.V.
	4358192	Screw
4	4359049	Capacitor, H.V.
5	4158368	Base Thermostat
	4358376	Screw
6	4359498	Motor, Turntable
	4358188	Screw
7	4359500	Plate
	4358192	Screw
8	4359501	H.V. Cable
9	4359502	H.V. Diode Cable
	4358489	Screw
10	4359503	Lead Wire
11	4359504	Guide
12	4359688	Cover
15	4359212	Tape
16	4359508	Rivet
17	4359689	Rotating Ring
18	4359618	Turntable Shaft
19	4358641	Glass Tray
20	4359510	Plate
	4358192	Screw

INTERIOR PARTS

For Models: MH6130XEB1, MH6130XEQ1

(BLACK) (DESIGNER WHITE)



1	4359511	Motor, Fan
	4359512	Screw
2	4359513	Air Duct
	4358188	Screw
	4358381	Screw
3	4158758	Blower Fan
5	4359514	Fuse
	4358381	Screw
7	4358775	Thermostat
8	4158267	Wire, Holder
9	4359517	Cover
	4358762	Screw
10	4359518	Lamp, Holder
11	4359625	Oven, Lamp
12	4359519	Motor, Ventilation
13	4359690	Lead, Wire
	4358489	Screw
14	4359121	Fuse
15	4358659	Fuse Cap
16	4359522	Power Cord

Following Parts Not Illustrated

SEALER		
	482338	Sealer, Silastic (3 Oz.)
	4158491	Installation Hardware

LATCH BOARD PARTS

For Models: MH6130XEB1, MH6130XEQ1
(BLACK) (DESIGNER WHITE)



1	4358794	Board, Latch
2	4158940	Micro Switch
3	4158941	Micro Switch
4	4358795	Lever Monitor
5	4358271	Screw

VENTILATION PARTS

For Models: MH6130XEB1, MH6130XEQ1
(BLACK) (DESIGNER WHITE)



1		Base Plate
	4359526	Black
	4358829	Screw
	4359525	White
	4358380	Screw
2	4359532	Bracket, Black
	4359527	Bracket, White
	4358829	Screw, Black
	4358380	Screw, White
3	4359686	Glass, Cooktop Lamp
4	4359529	Lead Wire Assy
5	4359530	Bracket
6	4359625	Oven Lamp
7	4359518	Lamp Holder
8	4358853	Air Filter

INSTALLATION PARTS

For Models: MH6130XEB1, MH6130XEQ1
(BLACK) (DESIGNER WHITE)



1	4158541	Exhaust Adapter
2	4158319	Exhaust Damper
3	4158321	Toggle Bolt/Wings
4	4158326	Toggle Wing
5	4158323	Screw
6	4158315	Screw
7	4158314	Washer
8	4358924	Plate, Mounting Wing
9	4358011	Clamp
10	4358012	Bushing
11	4359560	Sheet-Top Cabinet Template
12	4359011	Sheet-Wall Template
13	4358381	Screw
15	4358010	Screw
16	4358933	Pin, Locking